
Installation Instruction



Product name


TV Stand

Ver.1.0 20240601

Assembling

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips head screwdriver



Weight Limitation



60

30


lbs table top lbs per shel



What's included

Code	Description	Qty
Α	Cam Bolt M6X35MM	42
В	Cam Lock 15X10MM	42
С	Wooden Dowel M8X30MM	56
D	Screw M4X35MM	12
Е	Bolt M6X25MM	4
F	Metal Support	12
G	Screw M4X14MM	14
Н	Metal Wheel	4
I	Handle	2
J	Bolt M4X18MM	4
K	Metal Pin	2
L	Plastic Corner Support	16
М	Screw M3X14MM	16
N	Nylon Strap	2
0	Anchor M6X30MM	2
Р	Metal Strip	1

The Hardwares



IMPORTANT:


- 1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- 2. Do not over tighten screws and bolts to avoid stripping.
- 3. Please use hand tools to assemble this product. Do not use power tools.
- 4. Must need 2 people to assemble this product.




Included Accessories


Code	Description	Qty
1	Cabinet Top	1
2	Front Top Stretcher	1
3	Upper Middle Division Panel	1
4	Upper Shelf	1
5	Left Side Panel	1
6	Left Vertical Small Panel	1
7	Middle Left Division Panel	1
8	Middle Vertical Small Panel	2
9	Middle Right Division Panel	1
10	Right Side Panel	1
11	Right Vertical Small Panel	1
12	Front Middle Stretcher	1
13	Shelf	2
14	Bottom Panel	1
15	Bottom Short Panel	2
16	Bottom Back Long Panel	1
17	Bottom Front Long Panel	1
18	Upper Back Panel	2
19	Lower Back Panel	2
20	Left Door	1
21	Right Door	1
22	Middle Shelf	1


The Accessories





Noted:

















































































STEP 10 В х4 10 4 (5) 7 (5) 9 4 10
























































Proper Use

DO NOT use for commercial purposes

DO NOT use as a step stool or stand on table

DO NOT put hot serving liquid directly on the table top

DO NOT leave spilled liquid on the table top

DO NOT use table if damaged DO NOT exceed weight limit

DO NOT make temporary repairs

DO NOT use outdoor

Dear Customer:

Thank you for purchasing our product, we wish you satisfy our service, if you have any further questions or any quality issues, please show the belows number and don't hesitate to contact our Customer Service People:

W688202407