


MODEL: IG10600043C-1315

ITEM #307858



OWNER'S MANUAL

Woodland 13' X 15' Cedar Framed Pavilion w/ Galvanized steel Roof

TABLE OF CONTENTS

ASSEMBLY GUIDE02
USING YOUR PRODUCT04

January 06, 2026

QUESTIONS?








 E-mail: support@modernshade.org








 Toll Free Number: 1-888-666-3070

 Mon-Fri: 9:00 AM - 5:00 PM PST.
























ASSEMBLY GUIDE

PARTS LIST

| | | | | | |
|---|--|--|--|---|---|
| A Post (4 pieces)  | B Foot Base (4 pieces)  | C Foot Cover (4 pieces)  | D1 Cross Beam 1 (2 pieces)  | D2 Cross Beam 2 (2 pieces)  | D3 Cross Beam 3 (2 pieces)  |
| P0010011801 | P0030001501 | P0020001001 | P0040025201 | P0040025301 | P0040025401 |
| D4 Cross Beam 4 (2 pieces)  | D5 Cross Beam 5 (4 pieces)  | D6 Cross Beam 6 (4 pieces)  | D7 Cross Beam 7 (4 pieces)  | D8 Herringbone beam (4 pieces)  | D9 Central Rafter Support (2 pieces)  |
| P0040025501 | P0040025601 | P0040025701 | P0040025801 | P0070002401 | P0050012001 |
| D10 Rafter Side Support (4 pieces)  | E1 Support Bracket 1 (4 pieces)  | E2 Support Bracket 2 (4 pieces)  | E3 Support Bracket 3 (2 pieces)  | F1 Roof Rib 1 (1 pieces)  | F2 Roof Rib 2 (2 pieces)  |
| P0050012101 | P0050000505 | P0050000605 | P0050012201 | P0090021301 | P0090021401 |
| G Middle Cross Beam (8 pieces)  | H1 Roof Support 1 (16 pieces)  | H2 Roof Support 2 (4 pieces)  | H3 Roof Support 3 (2 pieces)  | H4 Roof Support 4 (4 pieces)  | H5 Roof Support 5 (4 pieces)  |
| P0080002701 | P0090021501 | P0090021601 | P0090021701 | P0090021801 | P0090021901 |
| J1 Roof Border 1 (2 pieces)  | J2 Roof Border 2 (2 pieces)  | J3 Roof Border 3 (2 pieces)  | J4 Roof Border 4 (2 pieces)  | J5 Roof Border 5 (2 pieces)  | J6 Roof Border 6 (2 pieces)  |
| P0090022001 | P0090022101 | P0090022201 | P0090022301 | P0090022401 | P0090022501 |
| J7 Roof Border 7 (2 pieces)  | K1 Connector 1 (2 pieces)  | K2 Connector 2 (8 pieces)  | K3 Connector 3 (2 pieces)  | K4 Connector 4 (2 pieces)  | K5 Connector 5 (4 pieces)  |
| P0090022601 | P0060016801 | P0060016901 | P0060017001 | P0060017101 | P0060017201 |

| | | | | | |
|---|--|---|---|---|--|
| <p>K6 Connector 6 (2 pieces)</p>  | <p>K7 Connector 7 (8 pieces)</p>  | <p>K8 Connector 8 (2 pieces)</p>  | <p>K9 Connector 9 (2 pieces)</p>  | <p>K10 Connector 10 (2 pieces)</p>  | <p>L1 Roof Cover 1 (2 pieces)</p>  |
| P0060017301 | P0110007501 | P0060017401 | P0110007601 | P0060017501 | P0120005601 |
| <p>L2 Roof Cover 2 (1 piece)</p>  | <p>M Middle Cross Beam Support (4 pieces)</p>  | <p>N Hook (1 piece)</p>  | <p>P Roof Cap (16 pieces)</p>  | <p>Z1 Roof Plate 1 (14 pieces)</p>  | <p>Z2 Roof Plate 2 (4 pieces)</p>  |
| P0120005701 | P0050012301 | P1000000100 | P1000002201 | P0130010499 | P0130010599 |

HARDWARE

| | | | | | |
|--|---|--|---|--|---|
| AA Bolt M5*25 (112+6 pieces)  | BB Bolt M5*40 (80+4 pieces)  | CC Bolt M8*35 (16+1 pieces)  | DD Bolt M10*80 (8+1 pieces)  | EE Bolt M5*25 (16+1 pieces)  | FF Bolt M6*20 (192+10 pieces)  |
| H0008008098 | H0008008122 | H0008008099 | H0008008123 | H0008008138 | H0008008036 |
| GG Bolt M6*55 (4+1 pieces)  | HH Bolt M8*25 (24+1 pieces)  | JJ Bolt M8*35 (16+1 pieces)  | KK Bolt M10*45 (8+1 pieces)  | LL Bolt M10*205 (8+1 pieces)  | MM Anti-slip Screw Nut (16+1 pieces)  |
| H0008008103 | H0008008236 | H0008008237 | H0008008170 | H0008008125 | H0008008126 |
| NN Four-claw Screw Nut M8*8 (40+2 pieces)  | PP Bolt Pin (12+1 pieces)  | QQ M5 Flat washer (16+1 pieces)  | RR M6 Flat washer (196+10 pieces)  | SS M8 Flat washer (56+3 pieces)  | TT M10 Flat washer (40+2 pieces)  |
| H0008008127 | H0008008109 | H0008008056 | H0008008057 | H0008008058 | H0008008141 |
| UU M5 Sealant Washer (16+1 pieces)  | VV M6 Sealant Washer (4+1 pieces)  | WW Double Open End Wrench M5/M6 (2 pieces)  | XX Wrench M10 (2 pieces)  | YY M6 Allen Key (2 pieces)  | ZZ M8 Allen Key (2 pieces)  |
| H0008008059 | H0008008060 | H0008008121 | H0008008142 | H0008008133 | H0008008129 |
| ZY Concrete Anchor M6*60 (8 pieces)  | ZX M6 Hex drill bit (1 piece)  | ZW M8 Hex drill bit (1 piece)  | ZV M10 Hexsocket drill bit (1 piece)  | ZU Phillips drill bit (1 piece)  | |
| H0008008095 | H0008008209 | H0008008210 | H0008008208 | H0008008215 | |

IMPORTANT:

This instruction manual contains important information necessary for the proper assembly and safe use of the product.
Read and follow all warnings and instructions before assembling and using the product.
Follow all warnings and instructions when using the product.
Keep this manual for future reference.
Installer/Assembler: leave these instructions with the consumer.

SAFETY ALERT KEY

⚠ DANGER

Indicates a hazardous situation that, if not avoided, will result in death or serious injury.

⚠ WARNING

Indicates a hazardous situation that, if not avoided, could result in death or serious injury.

⚠ CAUTION

Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates information considered important, but not hazard-related (e.g. messages related to property damage).

ASSEMBLY INSTRUCTIONS

- Please carefully unpack each of the components and hardware. check the components against the parts list and make sure there are no missing parts. lay pieces on cardboard or a soft mat to help protect the pieces from scratches.


⚠ CAUTION

Watch for sharp edges when handling the pieces, wear gloves to avoid injury.

- For ease of assembly, it is recommended to have 3 or more people and allow enough time to completely finish the assembly. assembly can take 6-8 hours. a step-ladder is required for assembly (not included).
- Follow step by step instructions, and follow all safety warnings provided with your tools.
- DO NOT tighten screws until all the screws and washers are properly installed. Tighten screws securely, do not over tighten.
- Gazebo should not be used in inclement weather and high winds.

STEP 01 Slide Foot Cover **C** and Foot Base **B** onto Post **A**. Use four (4) [AA] bolts to attach Foot Base **B** to Post **A**. Repeat to make the other three (3) assemblies.

[AA] x16




x4

STEP 02 Attach two (2) [NN] screw nuts to one end of Cross Beam **D4**. Position Cross Beam **D3** between Cross Beams **D4** and Connector **K1**, aligning all mounting holes.

From the side, insert two (2) [HH] bolts with two (2) [RR] flat washers and tighten them to secure the connection. Then, use two (2) [AA] bolts to fasten the top of Connector **K1**. Repeat the same steps to assemble the second set.

[AA] x4
[HH] x4
[RR] x4
[NN] x4




x2

STEP 03 Attach two (2) [NN] screw nuts to each Cross Beam **D7**

Attach two (2) [NN] screw nuts to both ends of Cross Beam **D5**. Use two (2) [HH] bolts and two (2) [RR] flat washers to attach both ends of **D5** to Cross Beams **D7**.

Repeat to make a second assembly.


- [HH] x8
- [RR] x8
- [NN] x16



x2

STEP 04 Combine Cross Beam assemblies **D3**/**D4** and **D7**/**D5**/**D7** together. At each solid-circle position, secure the beams using two (2) [BB] screws. At both ends, fasten the beams using one (1) [BB] screw at each square-marked position. At the center of the entire assembly, secure **K1** using four (4) [AA] screws to reinforce the connection. Repeat to make a second assembly.


- [AA] x8
- [BB] x36



x2

STEP 05 Attach two (2) [NN] screw nuts to one end of Cross Beam **D2**. Use two (2) [HH] bolts with two (2) [RR] flat washers to attach Cross Beam **D1** to **D2**. Repeat to make a second assembly.


[HH] x4
[RR] x4
[NN] x4



x2

STEP 06 Attach two (2) [NN] screw nuts to each Cross Beam **D6**. Attach two (2) [NN] screw nuts to both ends of Cross Beam **D5**. Use two (2) [HH] bolts and two (2) [RR] flat washers to attach both ends of **D5** to Cross Beams **D6**. Repeat to make a second assembly.


[HH] x8
[RR] x8
[NN] x16



x2

STEP 07 Combine Cross Beam assemblies **D1|D2** and **D6|D5|D6** together. At each solid-circle position, secure the beams using two (2) [BB] screws. At both ends, fasten the beams using one (1) [BB] screw at each square-marked position. Repeat to make a second assembly.

[BB] x44




x2

STEP 08 DO NOT TIGHTEN THE BOLTS COMPLETELY UNTIL STEP 9 IS COMPLETED, TO AVOID AFFECTING THE INSTALLATION OF THE SIDE BEAMS.

Attach the Cross Beam assembly **D7|D5|D7** to left Post **A** using one (1) [DD] bolt and [TT] washer in the top hole, and one (1) [LL] bolt, two (2) [TT] washers, and one (1) [MM] nut in the bottom hole. Attach the Cross Beam assembly to right Post **A** using one (1) [LL] bolt, two (2) [TT] washers, and one (1) [MM] nut in the top hole, and one (1) [DD] bolt and [TT] washer in the bottom hole. Repeat to make a second assembly.


[DD] x4
[LL] x4
[MM] x4
[TT] x12




x2

STEP 09 Attach the Cross Beam assembly **D6 D5 D6** to left Post **A** using one (1) [DD] bolt and [TT] washer in the top hole, and one (1) [LL] bolt, two (2) [TT] washers, and one (1) [MM] nut in the bottom hole. Attach the Cross Beam assembly to right Post **A** using one (1) [LL] bolt, two (2) [TT] washers, and one (1) [MM] nut in the top hole, and one (1) [DD] bolt and [TT] washer in the bottom hole. Repeat with the other assembly.

- [DD] x4
- [LL] x4
- [MM] x4
- [TT] x12




STEP 10 CRITICAL: SQUARE UNIT BEFORE PROCEEDING TO NEXT STEPS. ONCE SQUARE, TIGHTEN ALL HARDWARE.



STEP 11 Use two (2) [JJ] bolts and two (2) [SS] flat washers to attach the upper end of Support Bracket **E1** to cross beam on left corner of each side. Use two (2) [CC] bolts and two (2) [SS] flat washers to attach the lower end of Support Bracket **E1** to Post. Repeat with the other three (3) **E1**.


Use two (2) [JJ] bolts and two (2) [SS] flat washers to attach the upper end of Support Bracket **E2** to cross beam on right corner of each side. Use two (2) [CC] bolts and two (2) [SS] flat washers to attach the lower end of Support Bracket **E2** to Post. Repeat with the other three (3) **E2**.

[CC] x16
[JJ] x16
[SS] x32



STEP 12 Use eight (8) [AA] bolts to attach one (1) Connector **K3** to Post **A**. Repeat with the other **K3** and two (2) **K4**.


[AA] x32




STEP 13 Insert two (2) [PP] bolt pins to each Rafter Supports **D9** and **D10**.

STEP 14 Insert Rafter Supports **D9** and **D10** onto the Connectors **K1** on the short side of gazebo.

[PP] x12




x2




STEP 15 Insert one end of Herringbone Beam **D8** onto Rafter Supports **D9** and **D10**. Use two (2) [KK] bolts, four (4) [TT] flat washers and two (2) [MM] anti-slip screw nuts to attach the other end of **D8** to Connector **K3/K4** on the Post. Repeat with the other three (3) Herringbone Beam **D8**.


[KK] x8
[MM] x8
[TT] x16



STEP 16 Slide one (1) Roof Rib **F1** and two (2) **F2** onto two (2) Connectors **K8** as shown. Slide Connector **K9** onto each roof rib assembly connection, securing with nine (9) [FF] bolts and nine (9) [RR] flat washers.




STEP 17 Use one (1) [AA] bolt to attach one (1) Connector **K10** onto each roof rib assembly connection. Repeat with the other **K10**.




STEP 18 Attach Connector **K6** to each end of roof rib assembly, securing with two (2) [FF] bolts and two (2) [RR] flat washers.

[FF] x4
[RR] x4




STEP 19 Use two (2) [AA] bolts to attach both ends of roof rib assembly **F1 F2** with Connector **K6** to Herringbone Beam **D8**.

[AA] x4




STEP 20. Use one (1) [FF] bolt and one (1) [RR] flat washer to attach the upper end of Support Bracket **E3** to roof rib assembly **F1/F2**. Use one (1) [AA] bolt to attach the lower end of **E3** to Rafter Supports **D9**. Repeat with the other **E3**.

[AA] x2
[FF] x2
[RR] x2




STEP 21. Attach Hook **N** to the center of roof rib assembly **F1/F2**.



STEP 22 Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Connector **K2** to one end of Middle Cross Beam **G**. Repeat to make the other seven (7) assemblies.


[FF] x16
[RR] x16




x8

STEP 23 Attach the Connector **K2** on cross beams without tightening. Use one (1) [FF] bolt and one (1) [RR] flat washer to attach the upper end of Middle Cross Beam **G** to roof rib assembly **F1/F2**. Repeat with the other seven (7) **G**.

[FF] x8
[RR] x8




STEP 24 Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Middle Cross Beam Support **M** to Middle Cross Beams **G**. Repeat with the other three (3) **M**.



STEP 25 Use one (1) [FF] bolt and one (1) [RR] flat washer to attach one end of Roof Support **H1** to Middle Cross Beam **G**. Repeat with the other seven (7) **H1**.


Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Roof Support **H1** to Middle Cross Beams **G**. Repeat with the other seven (7) **H1** and four (4) **H2**.



STEP 26 Use one (1) [FF] bolts and one (1) [RR] flat washer to attach one end of Roof Support **H5** to Middle Cross Beam **G**. Repeat with the other three (3) **H5**.

Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Roof Support **H4** to Middle Cross Beams **G**. Repeat with the other three (3) **H4** and two (2) **H3**.


[FF] x16
[RR] x16



STEP 27 Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Roof Border **J4** to the lower end of Middle Cross Beams **G**. Repeat with the other **J4** and two (2) **J5** and **J6**.


Use one (1) [FF] bolt and one (1) [RR] flat washer to attach one end of Roof Support **J3** to the lower end of Middle Cross Beams **G**. Repeat with the other **J3** and two (2) **J7**.

[FF] x16
[RR] x16




STEP 28 Use three (3) [AA] bolts to attach upper end of Connector **K5** to Herringbone Beam **D8**. Use one (1) [FF] bolt and one (1) [RR] flat washer to attach the lower end of **K5** to Roof Borders. Repeat with the other three (3) Connectors **K5**

[AA] x12
[FF] x4
[RR] x4




STEP 29 Use one (1) [FF] bolt and one (1) [RR] flat washer to attach the upper end of Roof Border **J2** to roof rib assembly **F1**/**F2**. Use one (1) [FF] bolt and one (1) [RR] flat washer to attach rest holes of **J2** to Roof Support and Roof Border. Repeat with the other **J2** and two (2) **J1**

[FF] x20
[RR] x20




STEP 30 Use four (4) [AA] bolts to secure each Connector **K2** on Middle Cross Beam **G** to cross beams.

[AA] x32



STEP 31 Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Connector **K7** to the connection of Roof Borders. Repeat with the other seven (7) **K7**.

[FF] x16
[RR] x16




STEP 32 DO NOT tighten the bolts completely until all the bolts and washers are properly installed.

Overlap the edges of the adjacent roof plates **Z1** together.


Use one (1) [EE] bolt, one (1) [QQ] flat washer and one (1) [UU] sealant washer to attach each center hole of Roof Plates **Z1** to the frame.

- [EE] x4
- [QQ] x4
- [UU] x4



STEP 33 Use two (2) [GG] bolts, two (2) [RR] flat washers and two (2) [VV] sealant washers to attach one (1) Roof Cover **L2** to the top.

- [GG] x2
- [RR] x2
- [VV] x2




STEP 34 DO NOT tighten the bolts completely until all the bolts and washers are properly installed.

Overlap the edges of the adjacent roof plates **Z1** and **Z2** together.

Use one (1) [EE] bolt, one (1) [QQ] flat washer and one (1) [UU] sealant washer to attach each center hole of Roof Plates **Z1** and **Z2** to the frame.


- [EE] x12
- [QQ] x12
- [UU] x12



STEP 35 Use one (1) [GG] bolt, one (1) [RR] flat washer and one (1) [VV] sealant washer to attach one (1) Roof Cover **L1** to the top.


Repeat with the other **L1**.

- [GG] x2
- [RR] x2
- [VV] x2




STEP 36 Use two (2) [FF] bolts and two (2) [RR] flat washers to attach one (1) Roof Cap **P** to the lower end of Roof Plates. Repeat with the other fifteen (15) Roof Caps **P**

[FF] x32
[RR] x32





STEP 37 Use two (2) [ZY] expansion bolts to anchor each post Foot Base **B** please make sure the expansion bolts are fully anchored.



Outdoor Structure anchoring guide for anchoring gazebo to wood or concrete: If step 37, on page 22 in the assembly instructions is not properly completed, this will void the warranty.

⚠ WARNING! If your gazebo is not properly anchored, damage could occur. It is highly recommended for maximum safety that you mount and secure to wood or concrete footers. This is far better and safer than using ground stakes. The following are some examples of how to mount the structure to wood or concrete surfaces. Refer to local building codes or consider consulting a licensed contractor for assistance in the anchoring of this product.

| WOOD | CONCRETE |
|---|--|
|  |  |
| <p>Anchors should be drilled into joists or reinforced blocking (not only deck boards).</p>  <p>Recommended Hardware: Expansion Bolt</p> | <p>Pre-drill holes for appropriately sized concrete anchors.</p>  <p>Recommended Hardware: Expansion Bolt</p> |

If digging for foundation, please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines. Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

⚠ CAUTION
DO NOT climb or walk on roof for any reason.

- Our components are intended for privacy, decorative and ornamental use only.
- Product is NOT INTENDED for the following:
- A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
- As load bearing support for a building, structure, heavy objects or swings.
- Used in structures that trap wind, rain or snow that would create extra load on the product.
- Accumulated snow must be removed from roof.
- DO NOT climb or walk on roof for any reason.

LIMITED WARRANTY

We warrants this product against defects in materials and workmanship for a period of one (1) year from the original date of purchase. To the extent any such defects occur, our products will send the appropriate replacement part(s) at no charge.

This warranty does not cover:

- Inspection costs or labor for replacement of any defective parts);
- Incidental or consequential damages;
- Cosmetic defects which DO NOT affect performance;
- Normal wear and tear;
- Damage due to vandalism; acts of nature, including but not limited to wind, storms, hail, floods;
- Improper assembly, installation, or use;
- Discoloration or fading of the finish as a result of exposure to chemicals, spills, pool or salt water
- Corrosion/ rust.

Your product has been designed for safety and quality.

Any modifications made to the original product could compromise its structural integrity or function, and could lead to product failure or personal injury. As such, modifying this product voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY, and is not for commercial, contract or other non-residential purposes. Products disclaims all other representations and warranties of any kind, express or implied.

The warranty applies to the original purchaser and is non-transferable. It does not apply to purchases of display models, or when the product is sold on clearance or "as is".

We makes no warranty whatsoever in respect to accessories or parts not supplied with it. This warranty shall apply only within the boundaries of the United States of America and Canada. This warranty gives the original purchaser specific rights, and the original purchaser may also have other rights, which vary from state to state.

